



NEW SPA! DIRECTIONS

- 1- Flush garden hose with ½ tsp of chlorine granules, this is done by shutting off nozzle end of hose, put chlorine in faucet end of hose and let sit for 5-minutes, then flush. Water mold, bacteria, Etc... have collected in hose and will contaminate the spa water.
- 2- Filling spa with a garden hose **PRE-FILTER** is highly recommended.
- 3- Add ½ oz of the spa chlorine granules (99% sodium dichlor) to water for spas up to 500 gallons.
- 4- After temperature reaches 90° degrees 1-bottle of all natural **WATER TREATMENT & CONDITIONER**. (½-bottle for spas up to 250 gallons & 1-full bottle for spas up to 500 gallons.)
- 5- Run pumps on high with all jets open for 5-minutes & enjoy. Check your water with a reliable test strip the next day, and only adjust if necessary.
- 6- Add recommended amount every 3-months.

Note... New Spas are water tested at the factory and some still have this old water left in the lines. 'Shocking' the water with 1-oz of spa chlorine granules (99% sodium dichlor) the first day is recommended to resolve this issue. **Important: Always leave all jets including neck jets, waterfalls, etc.. Open slightly when spa is not in use, this will allow our enzymes to circulate fully within the spa. Shocking once a week is recommended.**

These chemical guidelines are to help maintain proper water chemistry in your spa. Please keep in mind that all spa water is different based upon water source and frequency of use. If you are not using a pre-filter have your water tested by your local dealer to determine what, if any, additional chemicals are needed. For residential use only. Use as directed. The purchaser assumes all liability and responsibility while using this product. Do not take internally. Keep out of reach of children. Use in conjunction with an EPA registered chlorine. Spa Chlorine Granules (99% Sodium Dichlor) is highly recommended.